

XCORE Palletizing Package

Operation Manual

V2.0



Guangzhou Auctech Automation Technology Ltd

Copyright © Guangzhou Auctech Automation Technology Ltd 2023 All rights reserved.

This document and parts must not be reproduced or copied by any third party without the written permission of Guangzhou Auctech Automation Technology Ltd.

Trademark Statement

The words or images like “AUCTECH” are protected by trademark registration. The registered trademark information can be found in the open trademark registration information.

All other trademarks or registered trademarks mentioned in this manual are the property of their respective owners.

Attention

Your purchase of products, services or features, etc., shall be subject to the commercial contract and terms and conditions of Guangzhou Auctech Automation Technology Ltd. All or part of the products, services or features described in this manual may not be within the scope of your purchase or use. Unless otherwise agreed in the contract, Guangzhou Auctech Automation Technology Ltd makes no representations or warranties, either express or implied, with respect to the contents of this manual.

Due to product version upgrade or other reasons, the contents of this manual will be updated from time to time. Unless otherwise agreed, this manual is used only as a guide, and all statements, information and recommendations in this manual do not constitute any guarantee either express or implied.

Guangzhou Auctech Automation Technology Ltd

Add:

Room 903, Building E1, Design City, No. 7, Hexian North Street, Helong Street, Baiyun District, Guangzhou City, CHINA

Tel: +86 20 84898493

E-mail: info@auctech.com.cn

Content

1.Palletizing Package Introduction	1
1.1 Adaptation description	1
1.2 Process package installation and uninstallation	1
2.Palletizing package Settings	6
2.1 Project Settings	6
2.2 BoxPallet module	10
2.2.1 module common configuration interface	10
2.2.2 loading point configuration	11
2.2.3 container configuration	13
2.2.4 pallet configuration	15
2.2.5 Stack configuration	17
2.2.6 script configuration	21
2.3 Script optimization	26
3.Palletizing exception handling	31

1. Palletizing Package Introduction

Palletizer technology package is a plug-in expansion scheme for palletizer applications, including multi-pallet robot, BoxPallet plug-in package and so on. This manual will provide information on how to configure and build palletizing applications. Palletizing process package is divided into two parts, the setting of process flow and the generation of palletizing instructions. Feature highlights include:

The feeding point and the middle obstacle avoidance road point can be customized

Provide interactive calibration flow of pallet coordinate system, tool offset and other parameters

Friendly interactive A/B dual stack configuration tool

Robot path reachability check function

Robot script one-click generation function

1.1 Adaptation description

Before installing the palletizing process package, it is necessary to ensure that the software version of the robot matches, specifically:

Control software version: V2.9.0 and above


You can query the version information of the robot on the About page after the robot is powered on. For how to open the “About” screen, see Section 7 of the XCORE- User Manual.

1.2 Process package installation and uninstallation


Palletised process package file for “BoxPallet-1.0.0.plugin” plug-in. The installation procedure is as follows:


- 1、 the welding process package into the U disk, U disk requires FAT32 format

- 2、 After the robot system is started, insert a U disk into the USB interface on the robot control cabinet.



- 3、 Log in to the robot system as user admin.——password: 123



- 4、 Click the user profile picture , select System Settings, as shown in Figure 1.




Figure 1

5、 Select the plug-in management function and click the “Add” button.




Figure 2

6、 select the USB flash drive and from the file list, find and select the “BoxPallet-1.1.1.plugin” plug-in package, as shown in Figure 3.




Figure 3

7、 After the plug-in package is installed, φ will be marked as shown in Figure 4. Newly installed plug-in packages will be enabled by default at κ . λ displays the name and version of the current plug-in package.




Figure 4

8、 After the palletizing process package is installed, open the main page, select “Program”, and click the button “New Program”, as shown in Figure 5.




Figure 5

9、Enter the program name and click the “OK” button (as shown in Figure 6) to enter the script setting interface (as shown in Figure 7).




Figure 6




Figure 7

10、 The installed palletizing process package, as shown in Figure 8 below, can be temporarily disabled by turning off the enable signal. Or click the Delete button to delete the package completely.




Figure 8

2.Palletizing package Settings

Palletizing process package setup, including engineering setup, BoxPallet module and script optimization.

Project setup: Create a palletizing executive

BoxPallet module: Set pallet scene related parameter definition

Script optimization: Improve the program functions and optimize the path planning of the robot arm

2.1 Project Settings

1、“Tool Settings” interface, as shown in Figure 9.

Click the “Settings” button

Select “Tool Settings”

Click the “Add” button




Figure 9

2、Install the tool, as shown in Figure 10.

The Z axis of the tool coordinate system is perpendicular to the plane where the suction cup is located, and the direction is the same as the opening of the suction cup

The plane formed by the X and Y axes of the tool coordinate system coincides with the surface of the suction box



Figure 10


3、 Set coordinate system parameters, as shown in Figure 11.

① : Enter the name of the coordinate system

② : Input six degrees of freedom bias

③ : Input tool quality

Click the “OK” button



AUCTECH ROBOT Manager

Power off | Project project_1 | Install Vertical | Tool def... 0kg | Obj default | JOG 100% Joint J... | Global Speed 100% | Manual | Real | Collision L3 | Check 56bc

Tool | User | Install | Variable | Safety | System Event | Other | Bg-Script | Plugins

Add TCP

Name: ①

Coordinate: ②

TCP calibration

X(mm): 0 | Y(mm): 0 | Z(mm): 0 | RX(°): 0 | RY(°): 0 | RZ(°): 0

Payload message: ③

Mass(kg): 0 | Inertia tensor(kg*mm²): X, Y, Z | CentroidX(mm): 0 | CentroidY(mm): 0 | CentroidZ(mm): 0


Cancel | Confirm

Figure 11

4、 Activate the tool coordinate system, as shown in Figure 12.

Select the generated tool coordinate system

Click “Set as Current”



AUCTECH ROBOT Manager

Tool | User | Install | Variable | Safety | System Event | Other | Bg-Script | Plugins

TCP

Index	Name	Position	Mass	Centroid	Action
1	default	0,0,0,0,0,0	0	0,0,0	...
2	we	0,0,0,0,0,0	0	0,0,0	...

Set default | **Set Active** | Modify | Delete

Figure 12

5、 Click the created project and click “Enter Program”.




Figure 13

6、 Add BoxPallet module.

Click the BoxPallet module on the “Instructions” page and drag it to the appropriate location in the programming area




Figure 14

2.2 BoxPallet module

The BoxPallet module defines a complex solution for palletizing application scenarios in the palletizing process package. This function can make it more convenient for users to define and set parameters.

BoxPallet module has five configuration function interfaces, which are described as follows:

Feeding point configuration: Set parameters related to feeding point

Box configuration: Set box dimensions, quality and other related parameters

Pallet configuration: Set pallet-related parameters for the palletizing box

Stack configuration: Set the number of stack layers and stack layout

Script configuration: Set waypoints and other functions in the palletizing process

2.2.1 module common configuration interface

1、 Enter the parameter configuration interface of BoxPallet module, as shown in Figure 15.

Click the “Programs” button

Select the module BoxPallet

Position (1) in the figure: Click to change the module name; Position (2) in the figure: click this area and enter the module comment

Select the “Parameter” card, click “Open Configuration Tool” and press




Figure 15

2.2.2 loading point configuration

1、Enter the loading point configuration interface, as shown in Figure 16.




Figure 16

2、teach the material spot.

Click the teaching point button and move the end of the mechanical arm above the top material point box by operating the teaching device

As shown in Figure 17, slowly move the end of the arm so that the suction cup is fully attached to the housing surface

Ensure that the surface of the suction cup is parallel to the surface of the container

Ensure that the Z-axis of the tool coordinate system is perpendicular to and downward from the plane where the suction cup is located

Ensure that the position and direction of each box at the feeding point are consistent

Click the “Record current position” button to jump to the loading point configuration interface

As shown in Figure 18, the font of “Feed point” appears green, click the “Next” button




Figure 17




Figure 18

2.2.3 container configuration

- 1、 Select the origin of the pallet.

Under the overhead Angle, select any corner of the pallet as the origin of the pallet coordinate system

As shown in Figure 19, the lower right corner of the pallet is used as the origin point



Figure 19

- 2、 Determine the pallet coordinate system.

Adjust the user's field of view as shown in Figure 20 so that the pallet origin is at the top left of the field of view

In this field of view, down the origin is the positive direction of the X axis of the pallet coordinate system

In this field of view, the right direction along the origin is the positive Y-axis of the pallet coordinate system




Figure 20

3、 Set box parameters.

Select any side of the box as the “front”. As shown in Figure 21, “Front” has been selected

As shown in Figure 22, the operating robot will fit the “front” of the box with the upper edge of the pallet, the side with the left edge of the pallet, and the bottom with the pallet

Set the box parameters in Figure 23, where L1(X direction), L2(Y direction)

Click the “Next” button




Figure 21




Figure 22




Figure 23

2.2.4 pallet configuration

- 1、Enter the “Pallet Configuration” interface, as shown in Figure 24, and fill in the pallet parameters.

Refer to the “first point” diagram in the figure, pallet side length D1 is the direction of pallet X

The pallet side length D2 is in the Y direction of the pallet




Figure 24

2、Pallet calibration.

Teach in the order of P1 to P4

Teach P1 point (as shown in the “first point” in Figure 24)

The box position shown in the previous step (box configuration) is denoted as P1 point

Teaching point P2 (as shown in the “second point” in Figure 25)

The robot will translate the box forward along the X axis at any distance (more than half of the side length of the pallet), place the box on the pallet, and confirm that the edge and bottom of the box are fitted. Record it as point P2

Teach P3 point (the “third point” in Figure 25)

Operate the robot to return to point P1, move forward along the Y axis for any distance (more than half of the pallet side length), and place the box on the pallet, similarly referred to as point P3

Teach P4 points (as shown in the “fourth point” in Figure 25)

Operate the robot back to P1 point, turn the box “front” to the bottom (180° in the top view), the same as P4 point

Complete the 4 teaching points and click the “Next” button




Figure 25

2.2.5 Stack configuration

1、 Set stack type parameters, as shown in Figure 26.

- ① Location: Choose A stack type
- ② Position: Set the boundary reference and enter the actual value in the margin

When stacking on the pallet, if there is a requirement for the spacing between the box and the pallet, please turn on this function, if there is no requirement, you can turn off this function

③ Position: Set the number of layers (palletizing height)

Layer 1 is the lowest layer on the pallet

As the number of layers increases, so does the number of layers

Each layer can be set up A stack or B stack




Figure 26

2、 Place the stack type, as shown in Figure 27.

① Position: Click the box button in any direction (it will be highlighted)

The arrow direction of the container in the figure is consistent with the definition of “front” in the container configuration

② Location: the pallet placement area is shown in the figure (when using the boundary reference, the placement area is in the area surrounded by the boundary reference line)

Place the box into the pallet placement area

Close to the pallet boundary or reference line, click to place, the box will automatically adsorb the border

If a box is placed on the pallet, click close to the box, and the newly placed box will be automatically adsorbed and attached to the existing box

To retype the stack, click the “Empty pallet” button






Figure 27


3、 Adjust the box, as shown in Figure 28.

Click on the box you want to adjust, and three ICONS appear icon

 : Using this icon, rotate the case clockwise (90° per click)

icon.  : Use this icon to delete the currently selected box

icon.  : Use this icon to confirm the direction and position of the current container

Click on the box to move the box (in the layout area) by dragging and dropping, and click on the icon once it is in place 





Figure 28

4、 Switch the stack type, as shown in Figure 29.

As shown in the picture, set the B-stack type

The same way to complete the B-stack layout

You can see both A stack (typeset) and B stack (currently typeset)

After configuring the A and B stacks, confirm the stack Settings for each layer

Avoid the upper and lower boxes falling due to the stack layout.

Click the “Next” button.




Figure 29

2.2.6 script configuration

1、Teaching three teaching points and their pullback points, as shown in Figure




Figure 30

Figure 30 (1) Position: teaching “waiting for loading point”

As shown in Figure 31, click the teaching point and move the robot to the position between the pallet and the feeding point

Raise to a certain height in the negative direction of the Z-axis of the world coordinate system (does not affect interference with other objects in subsequent motion)

Click the “Record current Location” button



Figure 31

Position (2) in Figure 30: Teach “loading obstacle avoidance point”

Operate the robot to move to the loading point (loading point Configuration section)

As shown in Figure 32, click on the teaching point and lift up (along the normal direction of the top surface of the box).

Similarly lift to a certain height (above the height of the “feed back point”)

Click the “Record current Location” button

As shown in Figure 30, “Feed back point” : Enter the height value (mm), the height is greater than 10mm

If there is a boot block, the height value is greater than the height of the boot block, as shown in Figure 32




Figure 32

Position (3) in Figure 30: Teach “pallet obstacle avoidance point”

Click the teaching point and move the robot to the top of the pallet

As shown in Figure 33, lift up (along the normal side of the top surface of the box)

Similarly lift to a certain height (higher than the height of the top box of the stack)

Click the “Record current Location” button

As shown in Figure 30, “Place a retracement point” : Enter the height value (mm), which is greater than 10mm



Figure 33

2、 Interlayer tolerance setting (in Figure 35), the effect is shown in Figure 34.

Enter the value of interlayer tolerance, the range is $[-100, +100]$, the unit is mm

Enter a positive value to expand the spacing between layers

Enter negative values to press the spacing between layers




Figure 34

3、 Motion speed, as shown in Figure 35.

As shown in Figure 35, the speed or speed of the actual motion can be adjusted by pulling the per




Figure 35

4、 Reachability test, as shown in Figure 35.

“Whether there is a lifting platform” : If the device is available, turn it on, and if not, turn it off

Lift Table Travel: Enter the actual value

“Accessibility Test” :

Check whether all boxes on the pallet can be placed in place

Test results are for reference only

Click the “Finish” button to jump to the program interface, as shown in Figure 36

Click the “OK” button to complete the configuration of BoxPallet module and generate script, as shown in Figure 37




Figure 36




Figure 37

2.3 Script optimization

1、 Set parameters of the “Start” module, as shown in Figure 38.

Operate the robot to move to the position of “waiting for loading point”

Click “Record current point” button, click “Confirm button”




Figure 38

2、 Set the “Group waiting signal” module, as shown in Figure 39.

By adding instructions, the robot continues to grab the box and start stacking

There are three ways to add instructions:

Example Setting an I/O port

Set up communication module

Set up the “Wait” module (execute according to fixed wait time)




Figure 39

3、 Set up the “Group custom crawl” module, as shown in Figure 40.

Add instructions to set the fetching mode

It can be realized by setting the I/O interface and communication




Figure 40

4、 Set the “Group custom lifting platform lifting” module, as shown in Figure 41.

Position (2) in the figure: the “Group lifting platform” module can raise the height of the lifting platform by loading the command module

Positions (1) and (3) in the figure: “Group middle waypoint” module. You can add new waypoints by loading the command module to prevent path interference during script running




Figure 41

5、 Set the “Group Custom placement” module, as shown in Figure 42.

Add instructions to set how to place the box

The box can be placed by setting the I/O interface and communication




Figure 42

6、 Set the “Group custom lifting platform lowering” module, as shown in Figure 43.

Position (2) in the figure: the “Group lifting platform lowering” module can reduce the height of the lifting platform by loading the command module

Positions (1) and (3) in the figure: “Group middle waypoint” module. You can add new waypoints by loading the command module to prevent path interference during script running




Figure 43

7、The mechanical arm returns to the initial position of the script, as shown in Figure 44.

Click the “Save Program” button

Click the “Drag Move” button

The robot moves in the mode of movej. Releasing stops the movement. In order to prevent the movej from bumping into other objects in its path, it is recommended that the user return to the waiting point in advance in a manual jog




Figure 44

Click as shown in Figure 45



Button to start running the script

Using Manual Mode, select Simulation mode to run the entire process

Use Manual Mode and select Real Machine mode to run the entire process

If trajectory interference or singularity occurs after the above two processes are executed, add instructions to the “Group Custom intermediate waypoint” module in the script and set a new waypoint to solve the problem

Using “Real Machine” mode, click “Automatic Mode” to run the whole process

The user can adjust the robot running speed by clicking the “global speed” button to make the rhythm meet the production demand

Click the “Save Program” button to solidify the entire script




Figure 45

3.Palletizing exception handling

Summarize the problems in the use of palletizing process package, and provide solutions to related problems.

No	Exception topic	Cause	Solution	Info
1	Case grab failure	The vacuum degree of the suction cup is insufficient	Adjust the vacuum valve pressure	
		There are depressions or cracks on the adsorption surface of the housing	Replace with a more complete box grab	
2	The palletizing box exceeds the pallets	The teaching point of the grab is different from the current state	Re-set the palletizing package	
		The position of stacked pallets is different from the position when teaching	1.Reset the pallet configuration in the BoxPallet module and all subsequent modules Block setting. 2.And fixed pallet position to prevent pallet deviation	
3				

Guangzhou Aucotech Automation Technology Ltd

Add: Room 903, Building E1, Design City, No. 7, Hexian North Street, Helong Street,
Baiyun District, Guangzhou City, CHINA

Tel: +86 20 84898493

E-mail: info@aucotech.com.cn

Web: www.aucotech.com.cn